




INSTALLATION MANUAL

1. Install the support bar ,adjust the 4 position ,and tighten it.

Attention:Do not use any corrosion liquid to clean the aluminum and other metal parts when daily maintenance.




TP-001


RoHS  **ISO9001:2000**

T O O L P I C T U R E


1.




Pencil




Level ruler




Drill machine




Rubber hammer



Cross screw driver







Tape




Allen wrench
(In the package)


Place the glass, fixed by the allen wrench




Accessory list




PJ-4044




PJ-4014



PJ-4015




PJ-4024




Glass





PJ-4013



LG-2007





1. Install the hanger fix part ,fixed by the allen wrench



4



1. As the picture show,make a mark by pencil ,Use tape to measure the distance,ensure it flat by leveruler.

The total length of the glass	A	B
1200mm	1020mm	550mm
1500mm	1320mm	550mm
1800mm	1620mm	550mm
2000mm	1600mm	550mm





1

1. Make the mark to fixed 8 positions, C=2.5CM
2. Drill hole on the fixed position



2

1. Install the fixed part, tighten the screws to fix it.



3